

TPS-500 X2 units quick guide.

Read before use.

Unpack the device(s):

Make sure that the device(s) are charged for at least 5 minutes. Make sure that the device(s) are powered up and at least one light is active. Press the Start/Stop button once on powerpacks and wait for the device to start.

Get the app (recommended):

Get InkMachines from the Apple App Store or Google Play. Check the current operating-system requirements in the app store before installing.

To pair devices with the app:

Once the app is installed, start the app and follow the instructions in the app to add your device(s). Or go to settings (upper left) and then press Devices. Then press the + sign (upper right) to add a device. Then hold the Pair button (center button for TPS-500 X2) for 5 sec until the lights start pulsing on the device then release the Pair button.

To pair devices without the app:

Press and hold the PAIR button on one of the physical devices until the light(s) start pulsing. (On the TPS-500 X2, hold the center button until “pairing” appears on the display). Then hold the PAIR button 5sec on second device you want to pair it with. The pair process will initiate and when it's complete, the devices will blink to confirm. Repeat the process for each device that you want to add to the system. If you have the TPS-500 main unit with charger bay the powerpacks will pair just by placing them on the charger bay.

Unpair and reset a device to stand alone:

Hold the PAIR button for about 12 seconds. The device light(s) will flash repeatedly to confirm. Unpairs the device from app, TPS 500 X2 or WFS X2 footswitch and reboots.

Compatibility mode:

If you intend to use the new X2 devices with the old TPS-500 system you can't have any of the devices paired with the app.

To pair a Scorpion X2 or Dragonfly/Stingray X2 powerpack to the old system just place it on the charger bay and it will automatically pair to the system.

To pair a WFS X2 foot switch to the old TPS-500 system you need to go to the tools menu in the old TPS-500 and scroll to pair footswitch and follow instructions on the TPS-500 display.

Important!

If you have more than one powerpack paired, the system needs to know which of the powerpacks / machines to start when pressing on for example with a foot switch.

The powerpacks have a built-in motion sensor so you will only have to give the machine / powerpack a light shake or tilt to make that machine active before you press the foot switch. A shake of the powerpack will also automatically change the page in the app to the active powerpacks corresponding work and settings page.

Power off devices:

Foot switch WFS X2:

Remove USB charger cable if attached. Hold down the large foot button and the pair button simultaneously for about 5 seconds.

To wake the device up, press the large foot button or attach the USB charging cable.

X2 Powerpacks:

Remove the powerpack from the machine.

Remove USB charger cable if attached.

Hold down Start/stop button for about 5 seconds. To wake up device, press the Start button or attach the USB charging cable.

TPS-500 X2 main unit:

It is recommended to leave the TPS main unit powered on, especially if you have powerpacks on the charger bay. The batteries will be maintained and always ready for use.

The main unit will go into sleep mode to save power after being unused for a while.

To power off all devices, go to Devices in the app and press "Turn off all devices"

If you experience any problems:

Restart the app and the device(s) or contact InkMachines info@inkmachines.com

Battery information and manuals



inkmachines.com/battery-information

InkMachines Sweden AB
Grusåsvägen 8, 352 45 Växjö, Sweden